

PHS APOLLO VAPOUR CONTROL MEMBRANE

Apollo 1.5 Vapour Control Membrane enables airtightness and vapour control in roof and wall constructions. This Vapour Control membrane is used indoors as a vapour check for achieving airtightness according to DIN 4108. Apollo 1.5 Vapour Control fulfils the requirements of EnEV and may easily be used for new buildings as well as for the renovation of old buildings.





Fitting Instructions



Interior




Exterior



1. The Sd Vapour Control membrane is applied to the building envelope on the warm side of the insulation.
2. The membrane should be rolled out to the correct length and cut with a sharp knife.
3. The membrane should be applied perpendicular to the timbers, with graphics facing the installer. (see fig 1.0) PHS 970 double sided tape at 400 - 600 centres should be used. (see fig 2.0) Otherwise staples 150-200mm apart, taking care to tape over the staples with PHS Argo, maintaining the integrity of your airtightness layer.
4. During initial positioning, creases should be removed, and minor pull tension applied to membrane.
5. The overlap joint should be sealed with a 60mm PHS Argo PET tape. Take care to apply the tape evenly between the membranes on the joint. (see fig 4.0 and fig 6.0)
6. All adhesion interfaces should be made secure by applying pressure on the adhesive with the PHS Roller (see fig 3.0)
7. After installation there should be no mechanical strain on the membrane, it's fixings and the joint, i.e. from insulation. If there is a risk of strain, cross-battening at 400mm centres should occur.
8. For fixing membrane to masonry apply a 6-8mm bead of PHS Ottello sealant to the masonry surfaces (see fig 5.0).
9. Gently press the membranes against the sealant and allow to dry. There should be a 3-4mm thick line of sealant after the final pressing, additional thickness will take longer to cure.
10. Ensure there is sufficient stress relief on the membrane's corners and trim back accordingly. (see fig 7.0)
11. Services penetrating the membrane should be sealed with PHS Argo or a suitable grommet.

* PHS Alkoe is a suitable alternative for the Argo tape.

- Membrane 1 must overlap Membrane 2 by **100mm**.
- Your joining tape (**PHS Argo**) shall be applied evenly over both membranes.



* To ensure a good adhesion, apply pressure on the tape with the PHS roller.

Other Products (Used in Application)



PHS Alkoe

PHS Alkoe Paper Tape is a hand tear-able sealing tape with an extremely high tensile resistance.



PHS 970

This Double-Sided can also be used to bond the membrane to a substrate.



PHS Ottello

This is a strong adhesive sealant used to make an airtight bond between the membrane and substrate.



Accessories

- PHS Sharp Knife
- PHS Roller, this insures an airtight adhesion.

* Please refer to the application instructions for other referenced products

Help Desk

Ireland : (021) 487 2664
UK : 333 880 2347

Passive House Systems products are used by a very diverse customer base for a wide range of technical and industrial applications. The demands made on our products vary considerably from application to application. We strongly advise users to test the products suitability for their own particular requirement and environment. All data and recommendations contained in datasheets and application guides are based on our own test results and practical experience and are aimed at helping customers select the appropriate products. This information is provided without liability. We reserve the right to change the technical specification without prior notice. Samples are available free of charge. Our sales teams are available to assist customers.